



# Software

## Multi Management Tool

### For the configuring of DC controllers MU2000 and UPC3

#### KEY FEATURES

- **Simple configuring of DC controllers UPC3 & MU2000**
- **Display of measured values of the system**
- **Display of device status**
- **Remote control of the DC controller**
- **Parameterizing of the remote displays**
- **Extensive battery management**
- **Graphic display of battery test data**
- **Extensive access control**

#### PRODUCT DESCRIPTION

The Multi Management Tool Software **MMT** enables user friendly configuring of our DC controllers UPC3 and MU2000 directly at PC. The MMT is designed for access via modem, RS232, USB and TCP/IP.

This software works dynamically. Information about the configuration and texts are read out from the controller unit and are displayed accordingly.

The MMT allows extensive user and access management with a maximum of seven access levels.

The benefits include simple parameterizing, display of event lists, measured values of the system and status. In addition there is an extensive battery management available:

Start/stop of battery test or boost charge, full graphic and tabular presentation of battery test data.


Furthermore remote control of the DC controllers UPC3 or MU1000 is possible via a simulated control panel at PC screen.

#### APPLICATIONS


All power supply systems which are controlled by DC controllers UPC3 or MU2000.




<b>Article</b>	<b>MMT (Multi Management Tool Software)</b>
Article code (single-user license)	302-UP3-MMT.00 (for Windows® 2000/XP/2003/Vista)/302-UP3-MMT.01 (for Windows® 7)
Article code ( license for ten users)	302-UP3-MMT.10 (for Windows® 2000/XP/2003/Vista)/302-UP3-MMT.11 (for Windows® 7)
<b>System requirements:</b>	
Software	compatible with Windows® 2000/XP/2003/Vista & Windows® 7 (32 and 64 Bit).
Modem	a modem installed with Windows® driver (TAP) is necessary
Communication	modem, RS232, USB, TCP/IP
<b>Compatibility</b>	
UPC3	from firmware UPC3 V1.14.149
MU2000	from firmware MU2000 V1.33.256
<b>User access management</b>	
UPC3	up to seven access levels are available for UPC3 firmware from V1.30.162; before it, two access levels are available
MU2000	two access levels




Screenshot „Configuring“



Screenshot „User management“



Screenshot „Measured values“



Screenshot „Battery test“